

Source:	Prestolite Electric Ltd - Greenford, London, UK
Date:	July 11, 2013
Bulletin No:	TSB4050
Models:	N1 type alternators
Subject:	Supplied pulleys

Prestolite equivalent N1 type alternators replace multiple cross-references. The basic alternator is identical, but in some cases the pulleys fitted varies.

We supply the most commonly found pulley. If you require a different pulley, please re-use your original pulley.

Changing the pulley does not affect your warranty conditions.

Pulley change procedure:

1. Use suitable workshop PPE to change pulley.
2. Use an impact wrench and suitable socket to remove the pulley nut and washer. Keep these for re-use.
3. Remove the pulley and clean the shaft, ensuring it is free from debris.
4. Fit replacement pulley, washer and shaft nut. Finger tighten the nut.
5. Using a pulley installer kit use 8mm hex key in the shaft hex profile to secure shaft while torquing the shaft nut.
Torque the shaft nut to 90Nm \pm 5Nm.



Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at: